


PART NUMBER DIAGRAM - 2-1/2" - 6" DC



ITEM NO.	DESCRIPTION	QTY	PART NO.
1	Spring Cap	2	S-4877-00
2	O-Ring	2	D-3506-00
3	Cover Bolt	12	B-2083-00
4	Gasket	2	D-3505-00
5	Check Assembly	2	W-7590-05
6	O-Ring	2	D-3507-00
7	Spring Assembly	2	W-8393-00
8	Roller	2	I-5866-00
9	Roller Pin	2	I-5867-06

ITEM NO.	DESCRIPTION	QTY	PART NO.
10	"E" Clip	4	I-3144-00
11	Seat Disc Retainer	2	G-3769-00
12	Hinge Bushing	2	D-3685-00
13	Seat Disc	2	D-3504-00
14	Disc Retaining Plate	2	E-2379-00
15	Disc Retaining Screw	6	B-1793-00
16	Hinge Pin	2	I-5868-06
17	Seat Housing	2	F-3090-00

REPAIRS KIT 2-1/2" - 6"


SEAT REPAIR KIT

4S-009-01: Kit includes items 2, 4, and 5

RUBBER REPAIR KIT

4S-009-02: Kit includes items 2, 4, 6, 12, and 13

PART NUMBER DIAGRAM - 8" - 10" DC



PARTS LIST - 8" & 10"

DOUBLE CHECK BACKFLOW PREVENTER – 8" & 10" DC PARTS LIST

ITEM NO.	DESCRIPTION	QUANTITY	PART NO.
1	Testcock	2	70-804-01
2	Cover Bolt	16	B-1800-00
3	Cover	2	W-9459-05
4	Pilot Pin	2	I-6411-06
5	Cam Bumper	2	I-6412-06
6	Gasket	2	D-3964-00
7	Spring Assembly	2	W-4373-05
8	Testcock	1	70-104-01
9	3/4" Nipple	1	K-3412-00
10	Nut	2	C-2039-00
11	Lock Washer	2	E-2276-00
12	Swing Arm	2	F-3235-05
13	Cam Positioner	2	I-6441-00
14	Cam Roller	4	I-6410-00
15	Stem Nut	2	C-2040-00
16	Compensator Bolt	2	B-2183-00
17	Roller Pin	2	B-2518-00
18	Check Stem	2	G-3980-06
19	Compensator Spring	2	A-1459-00
20	Spring Button	2	E-2497-06
21	Seat Retaining Disc	2	F-3225-05
22	Seat Disc	2	D-3961-00
23	Disc Retaining Plate	2	E-2494-00
24	Disc Retaining Screw	12	B-1754-00
25	Hinge Pin	2	B-2517-00
26	Seat	2	L-6137-05
27	Seat O-ring	2	D-3963-00
	Body	1	Consult Factory

REPAIR KITS FOR 8" & 10" DC

SEAT REPAIR KIT

4S-00E-06: Kit includes items 6 (gasket) and 10 – 27 (seat assembly w/ o-ring)

RUBBER REPAIR KIT

4S-00E-04: Kit includes (1) each: gasket (6), seat disc (22), and seat o-ring (27)