


MODEL 375XL and 375



Reduced Pressure Principle – Backflow Preventers 1/2" to 1"

Parts Drawing



**BACK
FLOW
PARTS
USA**

www.BackflowPartsUSA.com

AZ 888-396-6202

CA 909-316-7057

MODEL 375XL and 375



Reduced Pressure Principle – Backflow Preventers 1/2" to 1"

Repair Kit Components		1/2"				3/4"				1/2" and 3/4"								1"														
Item #	Item Description	RK12-375XLBV1	RK12-375BV1	RK12-375XLBV2	RK12-375BV2	RK34-375XLBV1	RK34-375BV1	RK34-375XLBV2	RK34-375BV2	RK34-375	RK34-375R	RK34-375V	RK34-375W	RK34-375BOF	RK34-375FLUSH	RK34-375-RVCOVER	RK34-375XLBVHD	RK34-375BVHD	RK1-375XLBV1	RK1-375BV1	RK1-375XLBV2	RK1-375BV2	RK1-375	RK1-375R	RK1-375V	RK1-375W	RK1-375BOF	RK1-375FLUSH	RK1-375-RVCOVER	RK1-375XLBVHD	RK1-375BVHD	
1	Wedge Screw												•(x2)														•(x2)					
2	Wedge												•													•						
3	O-Ring, Sleeve	•	•			•	•			•	•		•						•	•			•	•		•						
4	Sleeve												•													•						
5	O-Ring, #1 Check Seat									•	•	•											•	•	•							
6	#1 Check Seat									•		•											•		•							
7	Poppet Screw									•(x2)		•(x2)											•(x2)		•(x2)							
8	Check Seal Retainer									•(x2)		•(x2)											•(x2)		•(x2)							
9	Check Seal Ring									•(x2)	•(x2)	•(x2)											•(x2)	•(x2)	•(x2)							
10	Poppet									•(x2)		•(x2)											•(x2)		•(x2)							
11	#1 Check Spring									•		•											•		•							
12	#1 Check Spring Retainer									•		•											•		•							
13	O-Ring, #2 Check Seat									•	•	•											•	•	•							
14	#2 Check Seat									•		•											•		•							
15	#2 Check Spring									•		•											•		•							
16	#2 Check Spring Retainer									•		•											•		•							
17	O-Ring, Housing Inlet									•	•	•		•	•								•	•	•		•	•				
18	Test Cock											•(x3)													•(x3)							
19	Check Housing											•													•							
20	O-Ring, Housing Outlet			•	•			•	•	•	•	•		•	•							•	•	•		•	•					
21	O-Ring, Relief Valve Cover									•	•	•											•	•	•							
22	O-Ring, Relief Valve Seat									•	•	•											•	•	•							
23	Relief Valve Seat									•		•											•		•							
24	Relief Valve Spring									•		•											•		•							
25	Relief Valve Seal Retaining Screw									•		•											•		•							
26	Relief Valve Seal Ring									•	•	•											•	•	•							
27	Relief Valve Lower Plunger									•		•											•		•							
28	Diaphragm									•	•	•											•	•	•							
29	Relief Valve Upper Plunger									•		•											•		•							
30	O-Ring, Relief Valve Stem									•	•	•											•	•	•							
31	Relief Valve Cover											•				•									•					•		
32	Relief Valve Cover Screw, Short											•(x2)													•(x2)							
	Relief Valve Cover Screw, Long											•(x4)													•(x4)							
33	Inlet Ball Valve, 375XL	•				•														•												
	Inlet Ball Valve, 375		•				•														•											
34	Outlet Ball Valve, 375XL			•				•																								
	Outlet Ball Valve, 375				•				•																							
35	Housing, Blow-Out/Flush													•	•													•	•			
	Flush Hose Assembly														•														•			
36	Green Ball Valve Handle and Nut																•(x2)														•(x2)	
	Blue Ball Valve Handle and Nut																	•(x2)														•(x2)
	Test Cock Cap Plug											•(x3)													•(x3)							

Whole Goods (Available for individual sale)			
Item #	Item Description	3/4"	1"
18	Test Cock	18-860	
	Test Cock, Lead Free	18-860XL	

Item No.	Repair Kit Description
1/2"	
RK12-375XLBV1	Inlet Ball Valve Repair Kit, 1/2" 375XL
RK12-375BV1	Inlet Ball Valve Repair Kit, 1/2" 375
RK12-375XLBV2	Outlet Ball Valve Repair Kit, 1/2" 375XL
RK12-375BV2	Outlet Ball Valve Repair Kit, 1/2" 375
3/4"	
RK34-375XLBV1	Inlet Ball Valve Repair Kit, 3/4" 375XL
RK34-375BV1	Inlet Ball Valve Repair Kit, 3/4" 375
RK34-375XLBV2	Outlet Ball Valve Repair Kit, 3/4" 375XL
RK34-375BV2	Outlet Ball Valve Repair Kit, 3/4" 375

Item No.	Repair Kit Description
1/2" and 3/4"	
RK34-375	Complete Internals Repair Kit, 1/2" and 3/4" 375 and 375XL
RK34-375R	Rubber Repair Kit, 1/2" and 3/4" 375 and 375XL
RK34-375V	Complete Pressure Vessel Repair Kit, 1/2" and 3/4" 375 and 375XL
RK34-375W	Wedge Assembly Repair Kit, 1/2" and 3/4" 375 and 375XL
RK34-375BOF	Blow-Out/Flush Fitting Repair Kit, 1/2" and 3/4" 375 and 375XL
RK34-375FLUSH	Flush Kit, 1/2" and 3/4" 375 and 375XL
RK34-375-RVCOVER	Relief Valve Cover Repair Kit, 1/2" and 3/4" 375 and 375XL
RK34-375XLBVHD	Green Ball Valve Handle Repair Kit, 1/2" and 3/4" 375XL
RK34-375BVHD	Blue Ball Valve Handle Repair Kit, 1/2" and 3/4" 375

Item No.	Repair Kit Description
1"	
RK1-375XLBV1	Inlet Ball Valve Repair Kit, 1" 375XL
RK1-375BV1	Inlet Ball Valve Repair Kit, 1" 375
RK1-375XLBV2	Outlet Ball Valve Repair Kit, 1" 375XL
RK1-375BV2	Outlet Ball Valve Repair Kit, 1" 375
RK1-375	Complete Internals Repair Kit, 1" 375 and 375XL
RK1-375R	Rubber Repair Kit, 1" 375 and 375XL
RK1-375V	Complete Pressure Vessel Repair Kit, 1" 375 and 375XL
RK1-375W	Wedge Assembly Repair Kit, 1" 375 and 375XL
RK1-375BOF	Blow-Out/Flush Fitting Repair Kit, 1" 375 and 375XL
RK1-375FLUSH	Flush Kit, 1" 375 and 375XL
RK1-375-RVCOVER	Relief Valve Cover Repair Kit, 1" 375 and 375XL
RK1-375XLBVHD	Green Ball Valve Handle Repair Kit, 1" 375XL
RK1-375BVHD	Blue Ball Valve Handle Repair Kit, 1" 375